



Guía de usuario

Bocina Alta Fidelidad
PC-112082

Instrucciones:

- 1.- Conecta las bocinas a una fuente de audio con salida de 3.5 mm y al adaptador de corriente USB.
- 2.- Conecta el adaptador de corriente a la red eléctrica y enciende tu fuente de audio.
- 3.- Controla el volumen con la fuente de audio y/o con el control de volumen integrado en el cable.

NOTA: Las bocinas pueden ser conectadas a un puerto USB de una computadora, sin embargo, ya que este tipo de puerto sólo proporciona 2.5 Watts, las características del sonido cambian y la sonoridad baja. También puede resultar en distorsión para volúmenes altos. Recomendamos usar el adaptador de corriente para óptimos resultados.



Users guide

Hi-Fi Enhanced Bass Speakers
PC-112082

Instructions

- 1.- Connect the speaker to an audio source with 3.5 mm output and to the USB wall power adapter.
- 2.- Connect the USB wall power adapter to the power supply and turn on your audio source.
- 3.- Control the volume using the audio source and / or the volume control on cable.

NOTE: The speaker can be connected to a USB computer port, however, since this port only provides 2.5 Watts, the performance of the sound may vary and the volume decrease. It can also result in distortion when playing at high volume. We recommend using the AC USB charger for optimal results.